



NOTES:

A. DEVELOPER / CONTRACTOR RESPONSIBILITIES:

1. TAPE #14 COPPER WIRE TO THE TOP OF THE EMPTY CONDUIT
2. COIL 3 FEET OF WIRE IN METAL AND FIBERGLASS VAULTS
3. COIL 10 FEET OF WIRE IN CONCRETE VAULTS
4. PROVIDE AS-BUILT DRAWINGS WITH THE LENGTH OF THE CONDUIT AND LOCATION OF THE TRENCH FROM THE BACK OF THE WALK, CURB OR SURFACE FEATURE WHERE THE END OF THE CONDUIT IS BURIED. THE TRACER WIRE SHALL EXTEND TO THE END OF THE CONDUIT.

B. LPC CREW RESPONSIBILITY:

1. METAL ENCLOSURES: CONNECT THE #14 TO THE GROUND BUSS
2. FIBERGLASS ENCLOSURES: DRILL A HOLE 4" BELOW THE PENTA HEAD OR LATCH MECHANISM TO INSTALL THE GROUND LUG ASSEMBLY
3. CONCRETE VAULT: ROUTE THE #14 COPPER WIRE OUT THE TOP OF THE VAULT IN THE DIRECTION OF THE EMPTY CONDUIT

ELECTRIC SERVICES

CALL 1-800-922-1987 TO OBTAIN UTILITY LOCATES

NOT TO SCALE



CITY OF
LONGMONT
COLORADO

1100 S SHERMAN ST
LONGMONT, CO 80501

TRACER WIRE INSTALLATION

PHONE: 303-651-8386
FAX: 303-651-8796

Revision #:
Approved by:
Date Approved:
File: UG Drawings_2025

DETAIL

700-06